

INFORMATION & INSTRUCTIONS

WARNING

Do NOT run Opaque through your Copier or Printer.

General Use

The IMAGETRANS Opaque Transfer System is a thin white fabric patch used to transfer images onto dark fabric. Image your CL or Inkjet transfer paper, press the transfer paper to the Opaque, press the Opaque to the garment.

Heat Press Set-up

- Temperature: 375°F (190°C).
- Pressure: maximum.

Bonding Imaged Transfer to Opaque

- Place Opaque sheet on the heat press (fabric side up).
- Position imaged CL or Inkjet transfer paper with printed side face down on top of opaque sheet.
- Press for 5-10 seconds. Remove from press.
- Peel transfer paper away while warm.
- Trim as required.

Pressing Opaque to Garment

- Place garment on heat press and pre-press for 5 seconds.
- Remove backing paper from the Opaque sheet, exposing adhesive.
- Position Opaque on garment, sticky side down and cover with silicon sheet.
- Press for 20-30 seconds using maximum pressure.
- Open heat press and remove silicon sheet.

Washing Instructions

- Always turn textile inside out before washing.
- **Recommended:** Machine wash in cold water.
Optional: Machine wash in warm water (40°C).
- Use mild detergent. Do not use harsh or bleaching materials.
- **Recommended:** Hang dry
Optional: Tumble dry with cool or warm air setting. Do not use fabric softeners.
- After washing we recommend turning shirt inside out and ironing the image from the back.
- Do not Dry Clean

Tech Support: 1-800-565-5686 Fax: 1-800-565-5622
info@jotopaper.com www.jotopaper.com